


Disconnect the two wires from the speaker in the LEF master. These two wires now join to the input (I/P) of the TB-RC-AMP. The output (O/P) is then wired back to the speaker in the intercom. The power supply for the TB-RC-AMP needs to be separate from the one powering the LEF. This needs to be repeated for each master that requires an amplifier.

 <p>BC TECHNOLOGY LTD BCTEC HOUSE WALLIS CLOSE PARK FARM IND EST WELLINGBOROUGH NN8 6AG TEL: 01933 405050 FAX: 01933 405454</p>	TITLE: LEF MASTERS WITH AMPLIFIERS		DRAWING REF: LEF-5 & TB-RC-AMP	
	DATE: 28/02/05	CUSTOMER REFERENCE: LEF-5 + AMP		PG: 1 OF 1
	DRAWN BY: PAUL CAREY	DESCRIPTION: LEF-5 SYSTEM WITH TB-RC-AMP'S FOR VOLUME		